

PROTOCOL

Murine IFN- γ Single-Color 384-Well Enzymatic ELISPOT Assay

CONTENTS

- Murine IFN- γ Capture Ab
- Anti-murine IFN- γ (Biotin) Detection Ab
- Strep-AP
- CTL-Test™ Medium
- Diluent A
- Diluent B
- Diluent C
- Diluent Blue
- S1 (Blue substrate component 1)
- S2 (Blue substrate component 2)
- S3 (Blue substrate component 3)
- Plates: 384-well, high-protein-binding, PVDF filter plates
- Adhesive plate sealing sheet
- Protocol

PROCEDURE

DAY 0 — STERILE CONDITIONS

- Prepare *Murine IFN- γ Capture Solution* (see Solutions).
- Pipette 25 μ l/well *Murine IFN- γ Capture Solution*. Seal plate with parafilm and incubate at 4°C overnight. (Prewetting of plates with ethanol is neither required nor recommended for this kit.)

DAY 1 — STERILE CONDITIONS

- Prepare *CTL-Test™ Medium* (see Solutions).
- Prepare antigen/mitogen solutions at two times final concentration in *CTL-Test™ Medium*.
- Decant plate containing *Capture Solution* from Day 0 and wash one time with 150 μ l PBS.
- Plate antigen/mitogen solutions, 50 μ l/well. Ensure the pH and temperature are ideal for cells by placing the plate containing antigens into a 37°C incubator for 10-20 minutes before plating cells.
- Adjust cells to desired concentration in *CTL-Test™ Medium*, e.g.: 2 million/ml corresponding to 100,000 cells/well (cell numbers can be adjusted according to expected spot counts since 30,000-300,000 cells/well will provide linear results). Keep cells at 37°C in humidified incubator, 9% CO₂ while processing cells and until plating.
- Plate cells 50 μ l/well using large orifice tips. Once completed, gently tap the sides of the plate and immediately place into a 37°C humidified incubator, 9% CO₂.
- Incubate for 24 hours. Do not stack plates. Avoid shaking plates by carefully opening and closing incubator door. Do not touch plates during incubation.


DAY 2

- Prepare Buffer Solutions: PBS, distilled water and Tween-PBS (see Wash Buffers).
- Prepare *Anti-murine IFN- γ Detection Solution* (see Solutions).
- Wash plate two times with PBS and then two times with 0.05% Tween-PBS, 100 μ l/well each time.
- Add 25 μ l/well *Anti-murine IFN- γ Detection Solution*. Incubate at room temperature, two hours.
- Prepare *Tertiary Solution* (see Solutions).
- Wash plate three times with 0.05% Tween-PBS, 100 μ l/well.
- Add 25 μ l/well of *Tertiary Solution*. Incubate at room temperature, 30 minutes.
- During incubation, prepare *Blue Developer Solution* (see Solutions).
- Wash plate two times with 0.05% Tween-PBS, and then two times with distilled water, 100 μ l/well each time.
- Add *Blue Developer Solution*, 25 μ l/well. Incubate at room temperature, 15 minutes.
- Stop reaction by gently rinsing membrane with tap water, decant, and repeat three times.
- Air-dry plate for two hours in running laminar flow hood or for 24 hours face down on paper towels on bench top.
- Scan and count plate. (CTL has scanning and analysis services available and offers a trial version of ImmunoSpot® Software with the purchase of any kit. Email kitscanningservices@immunospot.com for more info.)



Visit our YouTube channel for several helpful videos on working with ELISPOT and FluoroSpot assays:
www.youtube.com/user/ImmunoSpot.

Protocols and technical resources available at
www.immunospot.com.



SOLUTIONS

All solutions should be freshly-made prior to use. It is important to quick-spin the vials before use to ensure content volumes.

- **CTL-Test™ Medium:** Prepare medium by adding 1% fresh L-glutamine. Amount of medium needed will depend on variables such as cell yield and number of samples tested but will be no less than 40ml for one full plate.
- **Capture Solution:** Dilute *Murine IFN- γ Capture Antibody* in *Diluent A*. For one plate, add 60 μ l of *Murine IFN- γ Capture Antibody* to 10ml of *Diluent A*.
- **Detection Solution:** Dilute *Anti-murine IFN- γ (Biotin) Detection Antibody* in *Diluent B*. For one plate, add 10 μ l of *Anti-murine IFN- γ (Biotin) Detection Antibody* to 10ml of *Diluent B*.
- **Tertiary Solution:** Dilute *Strep-AP Solution* in *Diluent C*, 1:1000. For one plate, add 10 μ l of *Strep-AP* to 10ml of *Diluent C*.
- **Blue Developer Solution:** Add the *Substrate Solutions* in sequential steps to 10ml of *Diluent Blue*.

For one plate:

Step 1 – Add 160 μ l of *S1* to 10ml of *Diluent Blue*. Mix well!

Step 2 – Add 160 μ l of *S2*. Mix well!

Step 3 – Add 92 μ l of *S3*. Mix well!

It is recommended to make the Blue Developer Solution within ten minutes of use and to keep it protected from direct light.

Wash Buffers (Not included)

For each plate prepare:

- 0.05% Tween-PBS: 100 μ l Tween-20 in 200ml PBS
- PBS, sterile, 100ml
- Distilled water, 100ml

TECHNICAL TIPS

- Upon successful completion of the assay, IFN- γ spots will be blue.
- To maximize the use of each plate, an adhesive plate-sealing sheet has been included that can be adhered to the top of the plate to cover unused wells for use in subsequent assays. Use your thumbs to firmly adhere the sheet to the plate and a razor blade to cut the sheet to expose only the necessary wells.
- We highly recommend the use of CTL Serum-free Media for freezing, washing, and testing cells. Even brief exposure to a mitogenic serum can cause high background while other sera can have suppressive effects. CTL also recommends using the CTL-LDC™ Kit for accurate live/dead cell counts.
- Deviations from specified temperatures, timing requirements, number of washing steps, and specified reagent preparation volumes may alter the performance of the assay.
- Plates may be washed manually or with a suitable automated plate washer with adjusted pin length and flow rate so membranes and spots are not damaged (CTL recommends the CTL 405LSR).
- To avoid damage to the PVDF membrane in the wells, do not touch the membrane with pipette tips or with the plate washer. The PVDF membrane is permeable and protected by an underdrain. Avoid direct contact between the well bottom and wet surfaces, including paper towels or any other materials that will absorb liquid.
- While processing plates, the PVDF membrane at the bottom of the wells must remain wet.
- When underdrain and gloves are wet, the underdrain may be slippery and difficult to remove. Wipe gloves and underdrain with paper towel before removing.
- After completion of the experiment, do not dry the ELISPOT assay plates at temperatures exceeding 37°C as this may cause the membrane to crack.
- Spots may not be readily visible while the membrane is still wet. Scan and count plates only after membranes have completely dried.
- Higher background appearing in the control wells can be potentially overcome using the following steps:
 - When working with precultured cells, wash the cells thoroughly in CTL-Wash™ prior to the experiment in order to avoid carryover of cytokines and other substances; use CTL-Test™ for testing cells.
 - The SmartCount™ module of the ImmunoSpot® counting software automatically recognizes spots over high background or uneven background, correcting background deviations. The Autogating™ module will help discern between T cell-derived and background spots. The CTL technical support team will gladly assist you with using the ImmunoSpot® Software for the analysis of complicated test results.
- Data analysis: The CTL ImmunoSpot® Analyzers along with the ImmunoSpot® Software have advanced features that permit automated, objective recognition of spots, gating and counting. An ELISPOT data management tool, SpotMap®, is also available to facilitate high-throughput ELISPOT work.

The CTL team will gladly assist you with data analysis and troubleshooting, as well as in customizing ELISPOT assays to suit your needs. Please contact us at kits@immunospot.com.



Visit our YouTube channel for several helpful videos on working with ELISPOT and FluoroSpot: www.youtube.com/user/ImmunoSpot.

Protocols and technical resources are available at www.immunospot.com.

See other side for Contents and Procedure.

For laboratory research use only. Not for use in diagnostic or therapeutic procedures.



Cellular Technology Limited • 20521 Chagrin Blvd. • Shaker Hts., OH 44122-5350 USA
+1 216-791-5084 Phone • +1 888-791-4005 Toll Free US • +1 216-751-1373 Fax
kits@immunospot.com • www.immunospot.com

CTL-Europe GmbH • Hans-Boeckler-Str. 19-29, 53225 • Bonn, Germany
+49 (0) 228 8544 78-0 Phone • +49 (0) 228 8544 78-22 Fax
ctl-europe@immunospot.eu • www.immunospot.eu